



CURB ADAPTER INSTALLATION INSTRUCTIONS


1 Remove the existing unit and any part of the original curb that is above the curb itself.



2 Clean the top of the existing curb rails and the duct supports removing any old gasket or sealant material.



3 Re-Apply supplied gasket to the perimeter of the curb and around the duct drops.



4 Place the curb adapter on the existing curb. Screw the adapter to the existing curb around the duct drops to ensure that the supply and return air does not leak and that the adapter does not slide out of place while the new unit is being installed.

5 Position the new unit on the curb adapter and follow the unit manufacturer's installation instructions to complete the installation.

